



www.KINGtester.com
610.279.6010

METAL HARDNESS TESTING MADE EASY

KING® Brinell KingScope™ Microscope

Constructed from stainless steel, the rugged and optically reliable KingScope is the most versatile microscope on the market today. Featuring a 20X pre-focused lens, the KingScope has a narrow nose-piece which easily fits into tight recesses, resulting in less grinding on castings, billets and dies. For added stability when performing flat work, a slip-on base adapter is included. A side opening in the microscope allows plenty of natural light for viewing, and a cordless movable pen light can be used in dim conditions. The KingScope meets ASTM E-10 specifications and the calibration is traceable to NIST standards.



ACCURATE

- ◆ 20x total magnification
- ◆ Accurate to nearest 0.1mm
- ◆ Pre-focused lens allows for a fast and accurate reading
- ◆ High quality optics
- ◆ Meets ASTM E-10 standards



VERSATILE

- ◆ Narrow nose piece fits easily into small areas
- ◆ Portable design
- ◆ Side opening and cordless light allows for easy reading in all light conditions
- ◆ Suitable for both laboratory and shop
- ◆ Sturdy, stainless steel construction



Base adapter included.

KING Tester Corporation is the industry leader in the manufacturing and distribution of portable Brinell hardness testers and most recently Rockwell testers. Our customers include some of the largest names in aerospace, rail, auto, foundries, steel and aluminum mills, calibration labs, oil and gas, heat treaters, wear parts, military, infrastructure, construction and utilities.

We are committed to quality. KING Tester received the ISO 17025 accreditation from the American Association for Laboratory Accreditation (A2LA). All KING Tester products are certified and calibrated per ASTM E10 standards.

KING Tester Corporation ◆ 308 Schell Lane, Phoenixville, PA 19460
www.KINGtester.com ◆ 610.279.6010 ◆ king@KINGtester.com